

JES-X320 Magnet

What you need : Scissor, cutter knife, adhesion bond(for woodwork recommended), Toothpick to apply adhesion bond to overlap width, tweezers

Top panel

Reverse overlap width

Glue together B

Reverse overlap width

Back Unit Front

Base

Overlap width A

Overlap width B

Mountain fold line

Cutoff line

Main coil L

Glue together A

Basic unit

Glue together B

Unit

Back Front

Main coil L Pole piece Main coil L

Main coil R piece Main coil R

Main coil R

Basic unit

Main coil R

Main coil L

Glue together A

Base

How to Make

- 1: Cut out along the cutoff line, glue on overlap width A (in blue) only and put each parts together.
Fold the top panel into two, and glue the reverse face.
- 2: Glue the overlap width B (in green) of each part, in the order of pole piece → main coil → basic unit → top panel → unit → base to complete.

Photo on completion